

# SPIN HANDLE INSTRUCTIONS

## Step 1

- Slip small sleeve over the bolt. (**Figure 1.1**)



**Figure 1.1**

## Step 2

- Slip large sleeve over small sleeve on bolt. (**Figure 2.1**)



**Figure 2.1**

## Step 3

- Insert thru pre-drilled hole. Attach nut and tighten. (**Figure 3.1**)



**Figure 3.1**